



## SEALING OF WINDSHIELD GLAZING RUBBER

# UPDATE

**Models Affected: All American (A3FE & A3RE only) Vision (BBCV)**

Please see the instructions below for sealing around the windshield glazing rubber if required.

**Warning: Always follow all Federal, State, Local and Shop safety standards and use proper safety equipment when performing these procedures. This procedure requires working from ladders or scaffolds to reach the top of the bus. Observe all safety precautions to secure the bus from rolling and for use of ladders or scaffolds.**

Park the bus on a level surface, apply parking brakes, turn off engine and remove ignition key.  
Chock

On all windshields with glazing rubber and windshield glass in place, apply 10028090 Sealant, Polyurethane, Manus, 75am, Black at joint of windshield glazing rubber and body panel on outside of unit. Sealant should be a continuous bead around the perimeter of the windshield glazing rubber.

Reference Service Update #SU1203, SEALANT APPLICATION GUIDELINES, for proper steps to prepare surfaces for sealer application, proper steps for actual sealer application, cleanup of surface areas after sealant is applied and information for proper cure times.

Return unit to service.

S U 1 2 1 1

S E R V I C E U P D A T E