Everv 7.000 kms

 Lube, Oil & Filter Change w/Multi-Point Inspection

> EXPRESSLANE FAST OIL CHANGES & MORE

ALL VEHICLES

MOPAR.

If your vehicle is equipped with an automatic oil change indicator system, it may illuminate as early as 5,600 kms. Severe-Duty conditions such as hot or cold ambient temperatures, towing or dusty conditions may require Lube, Oil & Filter changes every 6,500 kms.

For most vehicles, we recommend a Lube, Oil & Filter Change every 7,000 kms.

Speak with your Service Advisor to determine which interval works best for you.



Aftermarket floor mats will NOT be re-installed **IMPORTANT!** after a detail clean-up because they affect the safety of your vehicle. They will be left in the trunk of the vehicle to avoid the safety issue of 'Pedal Entrapment'. Please ask us about Mopar OEM Floor Mats.

Dashboard Dusting

Shampoo Floor Mats

Clean Dashboard

Clean Cup Holders

Shampoo Carpets

Interior Shampoo

Fabric & Vinyl Protection

Clean Wheels

Vacuum Trunk





