




SUBARU

**ADDED
SECURITY®**



Easy-View Plan Comparison Guide. Total protection and confidence, backed by Subaru.



What is **Added Security**®?

Added Security® is the only mechanical breakdown coverage backed by Subaru of America, Inc. Because almost every Subaru includes highly advanced, complex systems such as EyeSight® Driver Assist Technology, it's important to consider our Gold Plus plan because it covers all of the intricate components that can be very expensive to replace.

With all plans, if a covered component breaks, our certified Subaru technicians will fix it using only new or remanufactured Genuine Subaru Parts. Unlike third-party plans, Added Security also covers wear and tear of covered components, consequential damage to other components, struts, constant-velocity joints and many more parts.

Third-party agreements are designed to be profitable to the seller, but Subaru stands behind Added Security® because our goal is for you to have the best ownership experience possible.

There are two main plans:

Classic Plan: Covers most major components

Gold Plus Plan: Covers almost every other component in your vehicle. See the back cover for a partial list of covered components.



All Plans include:

Towing Allowance

All plans provide an allowance if you need a tow due to a covered failure.

Rental Car Allowance

All plans provide an allowance for up to five days if your Subaru needs to be kept in the shop overnight for a covered repair.

The Gold Plus Plan also includes:

Trip Interruption Allowance

The Gold Plus Plan provides coverage of up to \$500, per occurrence, towards your hotel and meals if you break down. While most third-party plans require the breakdown to be more than 100 miles from home, the Gold Plus Plan offers coverage at more than 50 miles.

Additional Services

Maintenance Plans

You can lock in the cost of regularly scheduled maintenance by including one of our Maintenance Plans when you purchase your Subaru. Simply select the plan that aligns with your vehicle's recommended maintenance schedule. Also, every new-car Added Security Maintenance Plan includes a coupon worth \$500 towards the purchase of your next new Subaru.



Plan

Powertrain Coverage

Powertrain coverage includes major engine, transaxle and differential components.

Plan

Gold Plus Coverage*

Gold Plus includes **all Classic and Powertrain coverage, plus virtually every other part of your Subaru**, including the components of our most sophisticated technologies.

Coverage includes:

- EyeSight® Driver Assist Technology¹
- Blind-Spot Detection²
- Rear Cross-Traffic Alert²
- Reverse Automatic Braking³
- DriverFocus™ Distraction Mitigation System⁴
- STARLINK® Multimedia
- STARLINK® Safety and Security⁵

The Gold Plus Advantage

State-of-the-art technologies such as EyeSight® Driver Assist Technology¹ are made up of complicated parts that are often costly to replace. With Gold Plus, you can rest assured that all of these components are covered.



Plan

Classic Coverage

To protect your investment beyond the standard Subaru Warranty, **Classic includes all Powertrain coverage, plus additional specific components/major systems.**

Coverage includes:

- Cooling & Fuel
- Steering
- Suspension
- Brakes
- Electrical Systems
- Air Conditioning

Other Products

Subaru Equity Shield Optimum Vehicle Protection (OVP)*

These additional protections can be purchased separately:

- Tire and Wheel Protection
- Windshield Protection
- Dent and Ding Protection

*See program details for further information, exclusions and state availability.

*Added Security® Gold Plus does not cover some components, including maintenance items, brake pads, windshield wiper blades, hoses, belts, and more. Please see your Subaru retailer for specific component coverage details.




Plan

Powertrain Coverage

Powertrain coverage includes major engine, transaxle and differential components.



*Added Security® Gold Plus does not cover some components, including maintenance items, brake pads, windshield wiper blades, hoses, belts, and more. Please see your Subaru retailer for specific component coverage details.



Plan

Classic Coverage

To protect your investment beyond the standard Subaru Warranty, **Classic includes all Powertrain coverage, plus additional specific components/major systems.**

Coverage includes:

- Cooling & Fuel
- Steering
- Suspension
- Brakes
- Electrical Systems
- Air Conditioning

*Added Security® Gold Plus does not cover some components, including maintenance items, brake pads, windshield wiper blades, hoses, belts, and more. Please see your Subaru retailer for specific component coverage details.

Plan

Gold Plus Coverage*

Gold Plus includes **all Classic and Powertrain coverage, plus virtually every other part of your Subaru**, including the components of our most sophisticated technologies.

Coverage includes:

- **EyeSight® Driver Assist Technology¹**
- **Blind-Spot Detection²**
- **Rear Cross-Traffic Alert³**
- **Reverse Automatic Braking³**
- **DriverFocus™ Distraction Mitigation System⁴**
- **STARLINK® Multimedia**
- **STARLINK® Safety and Security⁵**

Coverage also includes:

Air Bypass Valve
Air Flow Meter
Timing Chain Tensioner
Timing Chain Guide
Front Engine Mounting Bracket
Fuel Injection System including Injectors
Intake Manifold
Intercooler and Duct
Turbocharger Housing
Turbo Inlet Elbow
Wastegate Controller
DCCD Center Differential
DCCD Manual Switch, Control Dial, Relay and Control Module
Steering Angle Sensor
Roll Connector
Double Offset Joints
Rear Differential Assembly and internal parts
Ambient Sensor
Coolant Crossover and Pipe
Coolant Heater Pipe
Engine Fans
Engine Oil Cooler Lines and Mounting Bolt
Fan Control Amplifier
Engine Temperature Sensor
Heater Core Inlet/Outlet Pipe
Idle Pulley
In-Vehicle Sensor
Radiator Fan Control Unit
Radiator Reserve Tank and Bracket
Sun Load Sensor
Thermostat and Thermostat Housing
Throttle Body Coolant Pipe

Turbo Oil Delivery and Return Pipes
Turbo Oil Scavenge Pump
Water Bypass Pipe
Water Pump Pulley
Air Cleaner Housing
Air Intake Resonator and Duct
Air Supply System
Crankcase Vent Pipe
EGR Pipe and Heat Shield
EGR Modulator Valve and Manifold
EGR Cooler
Electronic Throttle Body Assembly
Fuel Evaporative Pipe and Clamp
Fuel Chamber, Damper and Cut Valve
Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
Fuel Tank
Vent Cover, Hose and Pipe
Rollover Valve
Two-Way Switch and Valve
Turbo Air Bypass Valve
Vapor Separator
Vacuum Pipe Assembly
Rear Cooling Unit Blower Motor
Receiver/Dryer
Accelerator Switch
Accelerator Pedal Return Spring Switch
Accelerator Pedal, Lever, Clip and Bracket
Auto Transmission Oil Cooler
Clutch Release
Clutch Fork Boot and Return Spring
Clutch Operating Cylinder
Clutch Hydraulic Line and Gasket
Clutch Master Cylinder and Connecting Link

Clutch Pedal, Washer and Bushing
Differential Dip Stick
Speed Sensor
Inhibitor Switch
Paddle Shifter
Key Lock Solenoid and Release Lever
Oil Temperature Switch
Park Switch
Pilot Bearing
Selector Cable, Linkage, Bushing and Clip
Selector Cable Pin and Bushing
Shift Lock Control Unit, Lever and Solenoid
Stop Light Switch
Transmission Revolution Sensor
Connecting Link
Crossmember Bushing
Front Strut Mount, Cover and Spring
Front Crossmember Support and Bracket
Hub Bearing Unit
Hub Bolt
Blower Motor Resistor
Blower Motor Transistor
Brake Fluid Indicator Switch
Cam Angle Sensor
Circuit Board
Clutch Switch
Crank Angle Sensor

Dash Warning Box
Electric Parking Brake Actuator
Duty Solenoid
ECU Unit
EGR Temperature Sensor
Cruise Control Electronic Module
Power Rear Gate Control Module
Power Rear Gate Drive Motor
Power Rear Gate Auto Closer
Fuse Box
Fuse Joint Box
GPS Antenna
Hand/Foot Brake Switch
Headlamp Adjuster Switch
Headlamp Adjuster Motor
Headlight Illumination Sensor
Auto Headlight Leveler CM

Heater Blower Fresh Air Actuator
Heater Blower Motor
Rear Heater Blower
Heater Mode Control Unit and Actuator
Ignition Key Light
Inner Lap Belt Switch
Intake Air Temp Sensor
Immobilizer Antenna and Transponder


Key/Seat Belt Warning Chime
Manifold Absolute Pressure Sensor
Manual Transmission Neutral Switch
Knock Sensor
Multifunction Display
Navigation Display

Navigation Unit and Bracket
Outside Temp. Sensor
Oxygen Sensor
Power Door Locks
Power Seat Limit Switch
Power Seat Linkage
Power Seat Reclining Motor

Power Seat Tilt Motors
Power Seat Slide Rail Motor
Power Sunroof Micro Switch and Control Unit
Power Window Circuit Breaker
Rear Window Washer Pump
Rear Window Defogger Grid
Rear Wiper Intermittent Unit
Body Integrated Unit
Rear Cooling Unit Switch
Seat Belt Switch
Seat Belt Warning Chime
Shoulder Belt Switch
Starter Interlock Switch

Trunk Light Switch
Turbo Air Temperature Sensor
Turbo Boost Sensor
Voltage Drop Resistor
Warning Unit Display
Wastegate Control Valve
Window Regulators
Center Console Latch
Compact Disc Player
Dash Speakers
Front Seat Belt Set
Radio
Front Seat Lift Frame and Side Rails
Glove Box Latch and Striker
Keyless Entry Transmitter
Rear Shelf Speakers
Security System Control and Receiver Modules
Sunroof Track, Cable and Guide
Third-Row Seat Belt Set
Third-Row Seat Back Frame and Hinge
Tire Pressure Monitoring System Transmitter and Control Module
Valve Body

And many more components



Other Products

Subaru Equity Shield Optimum Vehicle Protection (OVP)*

These additional protections can be purchased separately:

- Tire and Wheel Protection
- Windshield Protection
- Dent and Ding Protection

*See program details for further information, exclusions and state availability.

The Gold Plus Advantage

State-of-the-art technologies such as EyeSight® Driver Assist Technology¹ are made up of complicated parts that are often costly to replace. With Gold Plus, you can rest assured that all of these components are covered.

*Added Security® Gold Plus does not cover some components, including maintenance items, glass, brake pads, windshield wiper blades, hoses, belts, and more. Please see your Subaru retailer for specific component coverage details.



Powertrain ENGINE

Engine Block and all internal parts
Cylinder Heads and Valve Trains
Oil Pump and Oil Pan
Timing Belts or Gears and Cover
Water Pump
Flywheel
Intake and Exhaust Manifolds
Oil Seals and Gaskets

TRANSAXLE AND DIFFERENTIAL

Transaxle Case and internal parts
Torque Converter
Electronic Transmission Control Unit
Seals and Gaskets
Axle Shafts and Constant Velocity Joints
Propeller Shaft

Subaru Equity Shield

Optimum Vehicle Protection (OVP)*

TIRE AND WHEEL PROTECTION

Coverage for tire repair or replacement or wheel replacement due to covered road hazard

WINDSHIELD PROTECTION

Covers Windshield Repairs (cracks, chips, bullseyes) under 6 inches long

DENT AND DING PROTECTION

Covers Paintless Dent Repair (and hail damage up to \$1,000 of insurance deductible). All OVP products have: unlimited claims, zero deductible, no aggregate limits.

*See program details for further information, exclusions and state availability.

Classic

ENGINE

Valve Covers
Oil Sending Unit
Motor Mounts
Turbocharger Assembly
Fuel Injection System

TRANSMISSION

Transmission Mounts

ALL-WHEEL DRIVE

Constant Velocity Joint Boots
Center Support Bearings
Universal Joints
Wheel Bearings and Spindle Rear
Torsion Bars
Rear Control Arms
Hub Bearings

COOLING AND FUEL

Radiator
Heater Core
Engine Fan and Heater Fan
Fuel Pump
Fuel Lines
Fuel Tank
Fuel Sending Unit

STEERING

Steering Rack Assembly and all internal parts
Steering Column Shaft and Coupling
Universal Joints
Power Steering Pump
Seals and Gaskets

FRONT SUSPENSION

MacPherson Struts
Transverse Links/Control Arms
Shafts and Bushings
Ball Joints
Steering Knuckles
Wheel Bearings
Stabilizer Bar and Bushings Seals and Gaskets

BRAKES

Master Cylinder
Power Brake Assist Unit
Anti-Lock Braking System
Traction Control System
Wheel Cylinders
Hydraulic Lines and Fittings
Disc Brake Calipers
Seals and Gaskets

ELECTRICAL

Alternator
Voltage Regulator
Ignition Coil
Starter Motor & Solenoid
Wiring Harnesses
Engine Management Control Unit
Power Door Locks
Sunroof Motor
Power Window Motors and Regulators
Power Mirror Motors
Windshield Wiper Motors
Heater Blower Motor and Switch
Electronic Instrument Display
Trip Computer
Clock
Analog Dash Gauges
Speedometer Head
Horns
Electronic Relays
Manually Operated Switches

AIR CONDITIONING

Compressor
Clutch and Pulley
Condenser
Evaporator
Expansion Valve (Orifice)
Blower Motor
Compressor Seal
Receiver/Dryer

Gold Plus

Air Bypass Valve
Air Flow Meter
Timing Chain Tensioner
Timing Chain Guide
Front Engine Mounting Bracket
Fuel Injection System including Injectors
Intake Manifold
Intercooler and Duct
Turbocharger Housing
Turbo Inlet Elbow
Wastegate Controller
DCCD Center Differential
DCCD Manual Switch, Control Dial, Relay and Control Module
Steering Angle Sensor
Roll Connector
Double Offset Joints
Rear Differential Assembly and internal parts
Ambient Sensor
Coolant Crossover and Pipe
Coolant Heater Pipe
Engine Fans
Engine Oil Cooler Lines and Mounting Bolt
Fan Control Amplifier
Engine Temperature Sensor
Heater Core Inlet/Outlet Pipe
Idler Pulley
In-Vehicle Sensor
Radiator Fan Control Unit
Radiator Reserve Tank and Bracket
Sun Load Sensor
Thermostat and Thermostat Housing
Throttle Body Coolant Pipe
Turbo Oil Delivery and Return Pipes
Turbo Oil Scavenge Pump
Water Bypass Pipe
Water Pump Pulley
Air Cleaner Housing
Air Intake Resonator and Duct
Air Supply System
Crankcase Vent Pipe
EGR Pipe and Heat Shield
EGR Modulator Valve and Manifold
EGR Cooler
Electronic Throttle Body Assembly
Fuel Evaporative Pipe and Clamp
Fuel Chamber, Damper and Cut Valve
Fuel Filler Hose, Clamp, Cap and Pipe Fuel Lines
Fuel Tank
Vent Cover, Hose and Pipe
Rollover Valve
Two-Way Switch and Valve
Turbo Air Bypass Valve
Vapor Separator
Vacuum Pipe Assembly
Rear Cooling Unit Blower Motor
Receiver/Dryer
Accelerator Switch
Accelerator Pedal Return Spring Switch
Accelerator Pedal, Lever, Clip and Bracket
Auto Transmission Oil Cooler
Clutch Release
Clutch Fork Boot and Return Spring
Clutch Operating Cylinder
Clutch Hydraulic Line and Gasket
Clutch Master Cylinder and Connecting Link
Clutch Pedal, Washer and Bushing

Differential Dip Stick
Speed Sensor
Inhibitor Switch
Paddle Shifter
Key Lock Solenoid and Release Lever
Oil Temperature Switch
Park Switch
Pilot Bearing
Selector Cable, Linkage, Bushing and Clip
Selector Cable Pin and Bushing
Shift Lock Control Unit, Lever and Solenoid
Stop Light Switch
Transmission Revolution Sensor
Connecting Link
Crossmember Bushing
Front Strut Mount, Cover and Spring
Front Crossmember Support and Bracket
Hub Bearing Unit
Hub Bolt
Blower Motor Resistor
Blower Motor Transistor
Brake Fluid Indicator Switch
Cam Angle Sensor
Circuit Board
Clutch Switch
Crank Angle Sensor
Dash Warning Box
Electric Parking Brake Actuator
Duty Solenoid
ECU Unit
EGR Temperature Sensor
Cruise Control Electronic Module
Power Rear Gate Control Module
Power Rear Gate Drive Motor

Power Rear Gate Auto Closer
Fuse Box
Fuse Joint Box
GPS Antenna
Hand/Foot Brake Switch
Headlamp Adjuster Switch
Headlamp Adjuster Motor
Headlight Illumination Sensor
Auto Headlight Leveler CM
Heater Blower Fresh Air Actuator
Heater Blower Motor
Rear Heater Blower
Heater Mode Control Unit and Actuator
Ignition Key Light
Inner Lap Belt Switch
Intake Air Temp Sensor
Immobilizer Antenna and Transponder
Key/Seat Belt Warning Chime
Knock Sensor
Manifold Absolute Pressure Sensor
Manual Transmission Neutral Switch
Multifunction Display
Navigation Display
Navigation Unit and Bracket
Outside Temp. Sensor
Oxygen Sensor
Power Door Locks
Power Seat Limit Switch
Power Seat Linkage
Power Seat Reclining Motor
Power Seat Tilt Motors
Power Seat Slide Rail Motor
Power Sunroof Micro Switch and Control Unit
Power Window Circuit Breaker

Rear Window Washer Pump
Rear Window Defogger Grid
Rear Wiper Intermittent Unit
Body Integrated Unit
Rear Cooling Unit Switch
Seat Belt Switch
Seat Belt Warning Chime
Shoulder Belt Switch
Starter Interlock Switch
Trunk Light Switch
Turbo Air Temperature Sensor
Turbo Boost Sensor
Voltage Drop Resistor
Warning Unit Display
Wastegate Control Valve
Window Regulators
Center Console Latch
Compact Disc Player
Dash Speakers
Front Seat Belt Set
Front Seat Lift Frame and Side Rails
Glove Box Latch and Striker
Keyless Entry Transmitter
Radio
Rear Shelf Speakers
Security System Control and Receiver Modules
Sunroof Track, Cable and Guide
Third-Row Seat Belt Set
Third-Row Seat Back Frame and Hinge
Tire Pressure Monitoring System
Transmitter and Control Module
Valve Body
and many more components

Added Security® Gold Plus does not cover some components, including maintenance items, brake pads, windshield wiper blades, hoses, belts, and more. Please see your Subaru retailer for specific component coverage details.

1 EyeSight® is a driver assist technology, which may not operate optimally under all driving conditions. The driver is always responsible for safe and attentive driving. System effectiveness depends on many factors such as vehicle maintenance, weather and road conditions. See Owner's Manual for complete details on system operations and limitations. 2 Blind-Spot Detection, Lane Change Assist and Rear Cross-Traffic Alert are systems designed to assist the driver by monitoring the rear and side areas of the vehicle during a lane change or reversing and are not a substitute for safe and attentive driving. 3 The Reverse Automatic Braking System is not a substitute for safe and attentive driving. System effectiveness depends on many factors, such as vehicle maintenance, weather and road conditions. Always exercise caution and use vehicle mirrors and the Rear-Vision Camera when backing up. See Owner's Manual for complete details on system operation and limitations. 4 The DriverFocus™ Distraction Mitigation System is a driver recognition technology designed to alert drivers if their attention to the road wavers or if the driver's face appears to turn away. The driver is always responsible for safe and attentive driving. System effectiveness may be affected by articles of clothing worn on the head or face. See Owner's Manual for complete details on system operation and limitations. 5 Activation with subscription required. Includes a 3-year trial subscription to Safety Plus services and a 6-month trial subscription to Safety and Security Plus services. The Concierge plan can be purchased annually or monthly. A credit card on file will be required for specific packages and for renewal purposes. See your retailer for details.