



Time of Sale

Extended Protection



Peace of mind.

Canada & United States Coverage

FCPP covers your vehicle anywhere in Canada and the continental United States.

Direct Response

FCPP will quickly and efficiently handle your claim. Repair costs are paid directly to the repair facility on authorized services, saving you from out-of-pocket expenses and the inconvenience of waiting for reimbursement.

Transferable Coverage

In the event you choose to sell your vehicle, you can apply to transfer the coverage to the next owner for the remainder of Policy/Contract term.

Deductible

Plans have a choice of \$100 or \$200 deductible per repair visit, plus applicable taxes, on all covered repairs. In the event the same component fails again, no deductible will be charged for its repair or replacement.

Reducing Deductible

The selected deductible will be reduced by \$50 when repairs are performed at your selling dealer.

Experience Based Refund (EBR)

(Coverage included in select Mechanical Breakdown Policies)

If the Plan selected on your Mechanical Breakdown Insurance Policy includes EBR (Experienced Based Refund), you can apply for a refund as soon as the Policy has expired by time. Refunds are based on the amount you originally paid for the Policy, up to a maximum of \$2,000, less your deductible. Criteria for EBR claim include:

- Original Policyholder must still be registered owner of vehicle.
- No mechanical or any other benefit claims were made during the entire term.
- EBR claim must be requested and received in the allotted time frame.

*See EBR terms and conditions
on Policy for complete details*



Travel with peace of mind.

Travel with a First Canadian Protection Plan.

Are you worried about unexpected breakdowns and unforeseen costly repairs? Vehicles are built with thousands of specialized parts and hi-tech components. With the cost of repairs increasing an average of 5% per year, an expensive repair can be a financial burden.

FCPP can eliminate those worries. Choose one of our protection plans to guard you against these unplanned expenses.

Protect your investment with a First Canadian Protection Plan.



Extended Protection Plan

You have made a large investment in a vehicle. Now, invest in a protection plan for that vehicle.

Select the right plan for You.



1	Engine	●	●	●
2	Turbocharger/Supercharger	●	●	●
3	Transmission	●	●	●
4	Drive Axle	●	●	●
5	Transfer Case	●	●	●
6	Front Wheel Steering		●	●
7	Brakes		●	●
8	Electrical		●	●
9	Air Conditioner		●	●
10	Fuel System		●	●
11	Front & Rear Suspension		●	●
12	Heating/Cooling System		●	●
13	Emission Coverage*		●	●
14	Complete Coverage**			●

*Kilometre limits apply.
** See inside of brochure for the parts and services not covered.
Please see Policy/Contract for details.

Schedule of Coverage



ENGINE

Ultimate & Ultimate Wrap
Select Plus
Powertrain

Cylinder Block & Cylinder Heads	●	●	●
Pistons & Piston Rings	●	●	●
Connecting Rods & Bearings	●	●	●
Crankshaft & Crankshaft Main Bearings	●	●	●
OHC Carriers	●	●	●
Cover and Module	●	●	●
Camshaft & Camshaft Bearings	●	●	●
Cam Followers	●	●	●
Timing Chain or Belt	●	●	●
Timing Gears	●	●	●
Timing Chain Cover	●	●	●
Timing Chain Tensioners	●	●	●
Timing Chain and Belt Guides	●	●	●
Timing Belt Pulley	●	●	●
Engine Serpentine Belt Tensioner	●	●	●
Idle Pulley & Idle Pulley Bearings	●	●	●
Flywheel (excluding teeth)	●	●	●
Rocker Arms & Rocker Shafts	●	●	●
Rocker Bearings	●	●	●
Cylinder Head Valves	●	●	●
Valve Seals & Valve Seats	●	●	●
Valve Lifters & Valve Springs	●	●	●
Valve Retainers	●	●	●
Push Rods	●	●	●
Water Pump	●	●	●
Oil Pump/Oil Pump Housing	●	●	●
Harmonic Balancer	●	●	●
Oil Pan (excluding drain plug threads)	●	●	●
Intake Manifold	●	●	●
Exhaust Manifold	●	●	●
Valve Covers	●	●	●
Engine Mounts	●	●	●
Diesel Fuel Injection Pump	●	●	●
Diesel Vacuum Pump	●	●	●
Seals & Gaskets	●	●	●



TURBOCHARGER / SUPERCHARGER


Ultimate & Ultimate Wrap
Select Plus
Powertrain

Turbocharger/Supercharger Housing & All Internal Parts	●	●	●
Blowout Valves	●	●	●
Intercooler	●	●	●
Seals & Gaskets	●	●	●



TRANSMISSION

Transmission Case & All Internal Parts	●	●	●
Input Shaft	●	●	●
Master Clutch Cylinder	●	●	●
Torque Converter	●	●	●
Vacuum Modulator	●	●	●
Transmission Mounts	●	●	●
Oil Pan	●	●	●
Seals & Gaskets	●	●	●



DRIVE AXLE

Final Drive Housing	●	●	●
Drive Axle Case & All Internally Lubricated Parts	●	●	●
Differential Cover	●	●	●
Axle Shaft	●	●	●
Drive Shaft Universal Joint	●	●	●
Wheel Bearings	●	●	●
Hub Bearing Assembly	●	●	●
Tapered Wheel Bearings	●	●	●
Locking Hubs	●	●	●
Drive Shaft	●	●	●
CV (Constant Velocity) Joints	●	●	●
Drive Line Actuators	●	●	●
CV Boots	●	●	●
Seals & Gaskets	●	●	●



TRANSFER CASE

Ultimate & Ultimate Wrap
Select Plus
Powertrain

Transfer Case & All Internal Parts	●	●	●
Encoder Motor	●	●	●
Seals & Gaskets	●	●	●



FRONT WHEEL STEERING


Steering Box & All Internal Parts		●	●
Rack & Pinion Gear		●	●
Power Steering Pump		●	●
Power Steering Hoses		●	●
Steering Spindles		●	●
Pitman Arm		●	●
Idler Arm		●	●
Center Link		●	●
Upper Steering Column Shaft		●	●
Relays		●	●
Sensors		●	●
Seals & Gaskets		●	●



BRAKES

Master Cylinder		●	●
Vacuum Assist Booster		●	●
Hydro Assist Booster		●	●
Disc Brake Caliper		●	●
Wheel Cylinders		●	●
Compensating Valve		●	●
Metal Brake Hydraulic Lines		●	●
Combination Valve		●	●
Seals & Gaskets		●	●

Schedule of Coverage



ELECTRICAL

Ultimate &
Ultimate Wrap
Select Plus
Powertrain

Alternator		●	●
Digital Instrument Cluster		●	●
Instrument Panel Printed Circuit Board		●	●
Voltage Regulator		●	●
Starter Motor		●	●
Starter Solenoid		●	●
Starter Drive		●	●
Factory Engine Compartment Wiring Harness		●	●
Electronic Ignition Module		●	●
Distributor Pick-up Coil		●	●
Ignition Switch		●	●
Ignition Lock Cylinder		●	●
Ignition Coils		●	●
Front & Rear Wiper Motor		●	●
Body Computer/Control Module		●	●
Powertrain Control Module		●	●
Headlamp Motor		●	●
Heater & Air Conditioning Control Assembly		●	●
Blower Motor Resistor		●	●
Horns		●	●
Factory Installed Cruise Control Module		●	●
Cruise Control Transducer		●	●
Cruise Control Servo & Amplifier		●	●
Power Vent Window Motors		●	●
Power Window Motor		●	●
Serviceable Power Seat Motors		●	●
Power Mirror Motor (excluding assemblies)		●	●
Power Antenna Motor (excluding mast)		●	●
Convertible Top Motor		●	●
Serviceable Sun Roof Motor		●	●
Rear Window Defroster Grid		●	●
Washer Pump & Switch		●	●
Power Door Lock Actuator & Switch		●	●
Manually Operated Switches		●	●



AIR CONDITIONER

Ultimate &
Ultimate Wrap
Select Plus
Powertrain

Condenser		●	●
Compressor		●	●
Clutch Assembly & Pulley		●	●
A/C Lines & Hoses		●	●
Evaporator		●	●
High/Low Compressor Cut-off Switch		●	●
Pressure Cycling Switch		●	●
Orifice Tube		●	●
Seals & Gaskets		●	●



FUEL SYSTEM

Fuel Pump		●	●
Diesel Nozzles/Fuel Injectors		●	●
Fuel Tank		●	●
Mechanical Fuel Tank Sending Unit		●	●
Fuel Rail		●	●
Fuel Pressure Regulator		●	●
Metal Fuel Delivery Lines		●	●
Fuel Tank Selector Valve		●	●



FRONT & REAR SUSPENSION

Upper & Lower Control Arms		●	●
Control Arm Shafts or Bushings		●	●
Upper & Lower Ball Joints		●	●
Torsion Bars and Mounts or Bushings		●	●
Stabilizer Bar		●	●
Stabilizer Links and Bushings		●	●
King Pins		●	●
Spindle & Spindle Support		●	●



HEATING & COOLING SYSTEM

Ultimate &
Ultimate Wrap
Select Plus
Powertrain

Heater Core		●	●
Front & Rear Blower Motor		●	●
Engine Cooling Fan & Motor		●	●
Hydraulic Fan Clutch Hub		●	●
Radiator		●	●
Hot Water Valve		●	●




EMISSION SYSTEM*

AIR Pump		●	●
Cam Shaft Sensor		●	●
Canister Purge Solenoid		●	●
Canister Vent Solenoid		●	●
Knock Sensor		●	●
Crank Angle Sensor		●	●
EGR Solenoid		●	●
EGR Valve		●	●
Idle Speed Control Motor		●	●
Mass Air Flow Sensor		●	●
Manifold Pressure Sensor		●	●
O2 (Oxygen) Sensor		●	●
PCM Coolant Temperature Sensor		●	●
Serviceable Throttle Position Sensor (TPS)		●	●
Vacuum Pump		●	●

*Select Plus includes Emission component coverage up to 100,000 km on its odometer.

Schedule of Coverage

ULTIMATE & ULTIMATE WRAP Includes everything except for the parts and services specifically listed as not covered. Some examples of extra covered components are:


**ENGINE**

Ultimate & Ultimate Wrap


Select Plus

Powertrain


External Sensors				●
Block Heater				●

**TRANSMISSION**


External Sensors/Switches				●
Transmission Cooler Lines				●

**DRIVE AXLE**


Hub Bearing Assemblies				●
------------------------	--	--	--	---

**STEERING**

Steering Dampner				●
Steering Wheel				●
Variable Steering Assist Components				●
Power Steering Cooler				●

**BRAKES**

ABS Hydraulic Modulator				●
ABS Sensors				●
ABS Wiring Harness				●
Relays				●
Switches & Solenoids				●
Park Brake Cables				●
Hydraulic Control Unit				●

**AIR CONDITIONER**

Heated Doors				●
Mode Actuators				●
Blend Door Motors				●


**ELECTRICAL**

Ultimate & Ultimate Wrap


Select Plus

Powertrain

Complete Vehicle Wiring Harness				●
Manually Operated Switches				●
Radio, TV, VCR, CD Player, DVD Player				●
Electronic Transmitting Devices				●
Navigation Systems				●
Window Regulators				●
Heated Seats				●
Theft Deterrent System				●
Daytime Running Light Module				●

**FUEL DELIVERY**

Fuel Level Sensor				●
Fuel Gauge				●

**COOLING**

Resistors				●
Relays				●
Coolant Reservoir				●
Radiator Cap				●

WHAT IS NOT COVERED?

The following parts or components and associated labour are specifically excluded from all types of Coverage: Throttle body; start light ignition batteries; zippers; windshield wiper arms and linkage assembly; headlamp; projection lamp and tail-lamp assemblies; cup holders; ashtrays; dash pads; consoles; seat frames and springs; convertible top and convertible top frame structures (cables, motors, electronics and switches associated with the functioning of the convertible tops are included in the Ultimate Coverage); inside and outside door handles and hinges; shock absorbers; MacPherson strut assembly (including upper mounts and bearings); pipes and hoses (except steering and air conditioning pipes and hoses), lines and rubber brake hoses (except power steering pressure hoses, steel air conditioning lines, and steel brake lines); fastening devices such as clips, nuts, bolts, fasteners, and rivets; standard transmission clutch assembly; manual clutch disc or pressure plate and related bushings and bearings; manual and hydraulic linkages; corroded cables; secondary ignition components; glass (including mirror assemblies and heated windshields); lenses; sealed beams; light bulbs; sockets; fuses; cellular phones; brake rotors and drums; components of exhaust and emission systems not specifically identified as part of the Emission System covered under section B.2(m) in the Schedule of Coverage; components of any Lift Kit; catalytic converter; weather strips; run channels; trim; moldings; bright metal; chrome; upholstery and carpet; paint; outside ornamentation; bumpers; body sheet metal and panels; structural body parts; sun roof frame and assemblies; tires; wheels and rims; and wheel or rim-mounted sensors, wind noise, squeaks, rattles, or water leaks. Fridges and Stoves in vans are also excluded under this Policy/Contract.

Optional GPR Coverage

(Available on qualifying Mechanical Breakdown Contracts)

Guaranteed Price Rebate (GPR):

If you selected and paid the GPR Fee on an eligible plan, you can apply for a rebate claim as soon as the Contract term has expired by time. Rebates are based on the amount you originally paid for the Contract, up to a maximum of \$2,000, less your deductible. Criteria for the GPR claim include:

- Original Contract holder must still be registered owner of vehicle.
- No mechanical or any other benefit claims were made during the entire term.
- GPR claim must be requested and received in the allotted time frame.

See GPR terms and conditions on Contract for complete details



Additional Benefits Included in **All Levels of Coverage**

No Deductible will apply to the following benefits:



RENTAL

In the event of a covered breakdown, we will pay or reimburse you for receipted expenses to rent a replacement vehicle or reimburse you for actual taxi or public transportation expenses.*



TRIP INTERRUPTION

In the event that a covered breakdown occurs more than one hundred (100) kilometres from your home and results in a repair facility keeping your vehicle overnight, we will pay for receipted motel and restaurant expenses.*



EMERGENCY ROAD SERVICE

In the event your vehicle becomes disabled and requires on-site assistance, we will provide you with 24-hour Emergency Road Service **(1.800.516.3385)**, which includes Mechanical First Aid, Tire, Battery, Fuel Delivery, Towing and Locksmith Service.*

*Some restrictions apply - see Policy/Contract for complete details.



Mechanical Breakdown Contracts
Administrator / Obligor
First Canadian Repair Protection
320 Sioux Road
Sherwood Park, AB T8A 3X6



Mechanical Breakdown Policies
Administrator / Underwriter
Millennium Insurance Corporation
320 Sioux Road
Sherwood Park, AB T8A 3X6

Toll-Free PH: 1.800.381.2580
Local PH: 1.780.467.9575
Toll-Free FX: 1.800.304.4031
Local FX: 1.780.467.9812

*NOTICE: The contents provided in this brochure are only a summary of certain terms and conditions of the Policy/Contract. Please refer to the actual Policy/Contract for complete details of coverage and exclusions. Not all Policies/Contracts are available in all provinces, and specific provisions may vary based upon individual provincial requirements.