



SAFETY. PERFORMANCE. COMFORT.

THE BEST TIRES FOR YOUR VOLVO

VOLVO TIRE ADVANTAGE



YOUR VOLVO RETAILER OFFERS:

Original equipment tires best suited to your vehicle

Competitive pricing on all major brands

24-month road hazard protection*

Convenient one-stop tire solution

Installation and inspection by Volvo-trained technicians



*Road hazard coverage only applies to Volvo-recommended original equipment and alternative (OEM and OEA) tires.

Performance Categories

All-Season

Enjoy a smooth ride, long tread life, and year-round traction.



High Performance All-Season

Blend all-season traction with responsive handling and high-speed capabilities.



Winter

Plow through the winter weather with enhanced traction on snowy and icy roads.



High Performance

Get enhanced steering and handling in both wet and dry conditions.



Light Truck

Give your pickup, crossover or SUV all-season versatility in rain, snow or shine.



Volvo Sizes Up Their Tires


Tires influence your entire driving experience. As the only points of contact between your vehicle and the road, tires need to effectively transmit the forces of acceleration, braking and cornering. The right tires maximize your Volvo's load-carrying capacity, handling, and overall performance.

Volvo engineers select original equipment tires that meet the stringent specifications of each vehicle. Selection is based on comprehensive testing that covers the following:

Traction • Stability • Comfort • Road Noise • Tread Life • Load • Fuel Economy

Replacing the tires on your Volvo with those that meet the original equipment specifications will help maximize your vehicle's comfort, performance and safety.

Ask a Volvo service advisor which tires are best for your vehicle and driving habits.



Caring for your Tires

Inflate

Check your tire pressure on a weekly basis and before long journeys to prevent safety and performance issues.

Under-inflation reduces fuel efficiency and causes uneven wear on the tire's outside edges, increasing the risk of a failure and blowout.

Over-inflation causes more wear to the center and can cause the tire to separate from the belt. Over-inflation also causes harsh ride and poor handling.

Inspect

Even undamaged tires can lose over a pound of air pressure in just a month. Consult your owner's manual or driver's door jamb for the proper load and inflation of your tires. Visually inspect your tires for damage and tread wear.

If you don't know the condition of your tires, have them checked by your Volvo retailer. A multi-point inspection conducted by a Volvo service advisor will identify remaining tread depth and any damage or inflation issues that could compromise your vehicle.

Replace

As a tire's tread wears down, its ability to provide traction and prevent hydroplaning diminishes. Tread depth is measured in 32nds of an inch, and new tires generally have a 10/32" tread (about 8 millimeters).

Suitable tread depth depends on road conditions, but tires should be replaced if only 3/32" remains.

2/32" is the minimum legal tread depth in most states, and tires with less are dangerous and must be replaced.

When it's time to replace your tires, Volvo-trained technicians will install tires on your vehicle that maintain like-new performance. Your Volvo retailer carries original equipment tires by major brands.



BFGoodrich
Tires

Continental
TIRE

GENERAL TIRE

HANKOOK

MICHELIN

PIRELLI

UNIROYAL

BRIDGESTONE

DUNLOP
TIRES

GOODYEAR

KUMHO TIRES

NEXEN
NEXEN TIRE

TOYO TIRES

YOKOHAMA

