

Maintenance Checklist – Boxster/S (981) (2013)

Required Maintenance and Lubrication Service

* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

Maintenance (Labor Operation 03 16 00 ..) See Technical Manual

After 40,000, 80,000, 120,000, 160,000 miles etc. / 60,000, 120,000, 180,000, 240,000 km etc.

Note: If the mileage for scheduled maintenance is not reached, maintenance must be performed no later than after 4, 8, 12..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Electrics

Diagnosis system: Read out fault memory; reset maintenance interval

Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment

Horn: Check operation

Tires: Check tire pressure (TPM)

Batteries and ventilation hoses: Check condition

Electrical equipment as well as indicator and warning lights: Check operation

Inside of Vehicle

Pollen filter: Replace filter element

Seat belts: check function and condition

Door locks: check function

Front Luggage Compartment

Pollen filter: Replace pre-filter element

Check front lid lock and safety hook of the front lid for secure seating and function properly

Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level

Check firewall body drains for debris

Outside of Vehicle

Check wiper blades

Vehicle lighting: Check operation

All headlights: Check adjustment

Radiators and air intakes: Visual inspection for exterior debris and blockage

Under the Vehicle

Drain engine oil and change oil filter

Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage

Tires: Check condition

Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)

Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level

Steering gear: Visual inspection of the dust boots for damage

Tie rod ends: Check play and dust boots

Axle shafts/Drive shafts: Visual inspection of the dust boots for leaks & signs of damage/wear

Exhaust system: Visual inspection for leaks and damage; check mounting and heat shields

Rear Luggage Compartment

Air filter: Replace filter elements

Fill engine oil (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 LC)

Coolant: Check level and antifreeze protection level

Check firewall body drains for debris

Engine Compartment

Fuel lines and connections: Visual inspection for damage and leaks

Visual inspection for leaks (oils and fluids)

Additional Maintenance – Replace Spark Plugs (Labor Operation 03 81 00 ..)

Replace spark plugs: every 40,000 miles / 60,000 km or 4 years

Additional Maintenance - Drive Belt Labor operation 03 60 00 ..

Check drive belt at 40,000 miles (60,000 km) or every 4 years

Check drive belt at 100,000 miles (150,000 km) or every 10 years

Check drive belt at 160,000 miles (240,000 km) or every 16 years

Additional Maintenance every 60,000 miles / 90,000 km or 6 years (Labor Operation 03 83 00 ..)

Replace drive belt

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage

Additional Maintenance every 120,000 miles / 180,000 km or 12 years (Labor Operation 03 88 00 ..)

- Manual transmission: change oil
 - PDK transmission: change oil
 - PDK transmission: change clutch oil
-

Additional Maintenance every 2 years (Labor Operation 03 51 00 ..)

Change brake fluid (use only Original Porsche Brake Fluid)

Additional Maintenance every 4 years (Labor Operation 03 52 00 ..)

Replace tire sealant

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM, PASM & Sport switches, sports exhaust system, door mirror fold-in function, heater, air-conditioning system and instruments: Check operation
 - Oils, fluids: Visual inspection for leaks
-

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WP _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____