

**Maintenance Checklist – Panamera (V6)/S/S Hybrid/Turbo/GTS (2012-13)**

Required Maintenance and Lubrication Service

\* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

- Maintenance** (Labor Operation 03 16 00 ..) See Technical Manual  
After 40,000, 80,000, 120,000, 160,000 miles etc. / 60,000, 120,000, 180,000, 240,000 km etc.  
**Note:** If the mileage for scheduled maintenance is not reached, maintenance must be performed no later than after 4, 8, 12..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

**Electrics**

- Diagnosis system: Read out fault memory; reset maintenance interval
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure
- Batteries and ventilation hoses: Check condition
- Electrical equipment as well as indicator and warning lights: Check operation

**Inside of Vehicle**

- Seat belts: Check operation and condition
- Pollen filter: Replace filter element

**Outside of Vehicle**

- Check wiper blades
- Clean reversing camera lens
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Trailer hitch: Check operation
- Check firewall body drains and sunroof drains for debris
- Radiators and air intakes: Visual inspection for exterior debris and blockage

**Under the Vehicle**

- Drain engine oil and change oil filter (Every 10,000 miles/15,000 km, see separate Oil Change Sheets, PNA 000 162 KC)
- Tires: Check condition and tire pressure
- Underside of vehicle: Visual inspection for leaks (oil and fluids)  
Underbody covers: Visual inspection, check that all are securely fastened – replace any damaged or missing panels
- Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Axle joints: Check play; visual inspection of the dust boots for signs of damage
- Drive shafts: Visual inspection of the sleeves for leaks & signs of damage
- Steering gear: Visual inspection of the dust boots for signs of damage  
Tie rod ends: Check play and dust boots
- Exhaust system: Visual inspection for leaks and signs of damage; check mounts

**Engine Compartment**

- Fill engine oil (See separate Oil Change Sheets, PNA 000 162 KC)
- Visual inspection for leaks (oil and fluids)
- Fuel system lines and connections: Visual inspection
- Coolant and hoses: Check level and antifreeze, check condition of hoses
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
- PDCC: Check fluid level
- Power steering: Check fluid level

**Additional maintenance for spark plugs** (Labor operation 03 81 00 ..)

- Replace spark plugs: Panamera every 40,000 miles (60,000 km) or every 4 years
  - Replace spark plugs: Panamera S/GTS every 40,000 miles (60,000 km) or every 4 years
  - Replace spark plugs: Panamera S Hybrid every 40,000 miles (60,000 km) or every 4 years
  - Replace spark plugs: Panamera Turbo every 30,000 miles (45,000 km) or every 4 years
- 

**Additional maintenance 60,000 miles (90,000 km) or every 6 years** (Labor operation 03 83 00 ..)

- Replace PDCC reservoir
  - PDK transmission: Change oil
  - Replace supercharger drive belt: Panamera S Hybrid
- 

**Additional maintenance 80,000 miles (120,000 km) or every 4 years** (Labor operation 03 85 00 ..)

- Air filter/s: Replace element/s
- 

**Additional maintenance every 120,000 miles (180,000 km) or 12 years** (Labor operation 03 88 00 ..)

- Manual transmission: Change oil
  - Change all-wheel front differential drive oil
  - Change rear differential oil
- 

**Additional maintenance every 160,000 miles (240,000 km) or 16 years** (Labor operation 03 95 00 ..)

- Automatic transmission: Change ATF and ATF filter - Panamera S Hybrid
- 

**Additional maintenance every 2 years** (Labor operation 03 51 00 ..)

- Change brake fluid (use only genuine Porsche brake fluid)
  - Clutch: Change brake fluid & perform test and adaption (use only Original Porsche Brake Fluid) Panamera S Hybrid
- 

**Additional maintenance every 4 years** (Labor Operation 03 52 00 ..)

- Replace tire sealant
- 

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

- Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, automatic speed control, PSM switches, sports exhaust system, heater, air-conditioning system and instruments: Check operation
  - Oils, fluids: Visual inspection for leaks
- 

Road Test Performed - Technician Signature: \_\_\_\_\_

**Customer Name:** \_\_\_\_\_

**Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  Miles  Kilometers: \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_

**Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_