

Maintenance Inspection

Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid / 4 E-Hybrid as of 2017 model

Name		Date	
License No.		Mileage/km	
VIN		Repair Order	

Inspection At 20,000, 40,000, 60,000, 80,000 miles/30,000, 60,000, 90,000, 120,000 km etc.
(For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual).

Note If the mileage for an inspection is not reached, an inspection must be carried out every 2 years at the latest.
The term 'checking' includes all necessary subsequent work, such as adjustments, readjustments, corrections and topping up, but does not include repairs, replacements or overhaul of parts or assemblies.

			Panamera (971) All Models	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 60 tmls/90 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 120 tmls/180 tkm or 12 years	Time-dependent
	Electrics	Windshield wiper/washer system, headlight cleaning system: check function	•	☐						
		Horn: check function	•	☐						
		Tires: check tire pressure (TPM)	•	☐						
		Diagnostic system: read out fault memory; reset maintenance interval	•	☐						
		Check actuator travel of brake shoes	•	☐						
	Inside the vehicle	Pollen filter: replace filter element	•	☐						
		Seat belts: check function and condition	•	☐		☐				
	Outside the vehicle	Check wiper blades	•	☐						
		All headlights: check adjustment	•	☐						
		Battery vent hose: check condition	•	☐						
		Tires: check condition	•	☐						
		Radiators and air intakes: visual inspection for debris and blockage	•	☐						
		Brake system: check brake pads and brake discs for wear (without removing wheels)	•	☐						

Maintenance Inspection

Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid / 4 E-Hybrid as of 2017 model

Measures

			Panamera (971) All Models	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 60 tmls/90 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 120 tmls/180 tkm or 12 years	Time-dependent
	Outside the vehicle	Brake system: check brake pads and brake discs for wear	•	☐		☐				
		Vehicles with PCCB: PCCB Brake discs must be checked for wear during every service and whenever brakes pads are replaced using special tool VAS 6813	•	☐						
		Check front firewall body drains for debris	•	☐						
		Check sunroof and rear lift gate body drains for debris	•	☐						
	Under the vehicle	Drain engine oil (See separate Oil Maintenance Sheet PNA 000 162 KL)	•	☐						
		Underbody panels: visual inspection for completeness, secure installation and damage	•		☐					
		Visual inspection for leaks from underneath (oils and other fluids)	•		☐					
		Brake lines: visual inspection for damage, routing and corrosion	•	☐						
		Brake hoses: visual inspection for damage	•	☐						
		Drive shafts: visual inspection of the boots for leaks and damage	•	☐						
		Steering gear: visual inspection of the bellows for damage	•		☐					
		Tie rod joints: check play and dust bellows	•		☐					
		Axle joints: check the play and visually inspect the dust boots for damage	•		☐					
		Exhaust system: visual inspection for leaks and damage, check engine mount	•		☐					
		PDK transmission: change oil	•			☐				
		All-wheel final drive: change oil	•					☐		
		Rear final drive: change oil	•					☐		
	Engine compartment	Change oil filter (See separate Oil Maintenance Sheet PNA 000 162 KL)	•	☐						
		Fill in engine oil	•	☐						
		Windshield wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use windshield cleaners approved by Porsche	•	☐						

Maintenance Inspection

Panamera / S / Turbo / S / E-Hybrid / S E-Hybrid / 4 E-Hybrid as of 2017 model

		Measures		Panamera (971) All Models	Every 20 tmls/30 tkm or 2 years	Every 30 tmls/45 tkm or 4 years	Every 40 tmls/60 tkm or 4 years	Every 60 tmls/90 tkm or 4 years	Every 80 tmls/120 tkm or 4 years	Every 120 tmls/180 tkm or 12 years	Time-dependent
	Engine compartment	Coolant: check level and antifreeze	•	☐	☐						
		Replace spark plugs	•		☐						
		Fuel lines and connections: visual inspection	•			☐					
		Air cleaner: replace filter element	•					☐			
+ 2 y.	Additional work every 2 years	Change brake fluid (use only original Porsche brake fluid)	•								☐
		Tire sealing compound: check use-by date and replace if necessary	•								☐
	Test drive	Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function	•	☐							
		Oils, fluids: visual inspection for leaks	•	☐							

Signature (technician): _____



Porsche Dealer Stamp