

## Intermediate Maintenance Checklist – 911 Carrera/S (991) (2012-on)

Required Maintenance and Lubrication Service

* Oil Change Every 10,000 miles (15,000 km) or 1 year. See Below Check Box.
Intermediate Maintenance (Labor Operation 03 14 00) See Technical Manual After 20,000, 60,000, 100,000, 140,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc. Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10 years.
The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.
Electrics
☐ Diagnosis system: Read out fault memory; reset maintenance interval
☐ Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
☐ Horn: Check operation
☐ Tires: Check tire pressure (TPM)
■ Batteries and ventilation hoses: Check condition
☐ Electrical equipment as well as indicator and warning lights: Check operation
Inside of Vehicle
Pollen filter: Replace filter element
Front Luggage Compartment
Pollen filter: Replace pre-filter element
☐ Check front lid lock and safety hook of the front lid for secure seating and function properly
☐ Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
☐ Check firewall body drains for debris
Outside of Vehicle
☐ Check wiper blades
☐ Vehicle lighting: Check operation
☐ All headlights: Check adjustment
Radiators and air intakes: Visual inspection for exterior debris and blockage
Under the Vehicle
☐ Drain engine oil
☐ Tires: Check condition
☐ Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)
☐ Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
■ Axle shafts: Visual inspection of the dust boots for leaks & signs of damage
Engine Compartment
Change oil filter and fill engine oil (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 LC)
☐ Coolant: Check level and antifreeze protection level
PDCC: Check fluid level
☐ Check firewall body drains for debris
Additional Maintenance - Replace Spark Plugs (Labor Operation 03 81 00)
Replace spark plugs: every 40,000 miles / 60,000 km or 4 years
- Topiaco opanii piago: etely topoco illinory copoco illinor i young
Additional Maintenance - Drive Belt Labor operation 03 60 00
☐ Check drive belt at 40,000 miles (60,000 km) or every 4 years
☐ Check drive belt at 100,000 miles (150,000 km) or every 10 years
Check drive belt at 160,000 miles (240,000 km) or every 16 years
Additional Maintenance every 60,000 miles / 90,000 km or 6 years (Labor Operation 03 83 00)
☐ Replace PDCC reservoir
Replace drive belt
Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00)
Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage
Additional Maintenance every 120,000 miles / 180,000 km or 12 years (Labor Operation 03 88 00)
☐ Manual transmission: change oil
PDK transmission: change oil
☐ PDK transmission: change clutch oil

Additional Maintenance every 2 years (Labor Operation	03 51 00)
lacksquare Change brake fluid (use only Original Porsche Brake Fluid	1)
Additional Maintenance every 4 years (Labor Operation	1 03 52 00)
☐ Replace tire sealant	
Inspection Performed - Technician Signature:	
Road Test Check	
Remote control, front seats, foot brake and electric parkin transmission, ParkAssist, cruise control, PSM, PASM & Sption, heater, air-conditioning system and instruments: Chec Oils, fluids: Visual inspection for leaks	ort switches, sports exhaust system, door mirror fold-in func-
Road Test Performed - Technician Signature:	
Customer Name:	Date:/
VIN: WPO	
Mileage (check one)  Miles  Kilometers:	
Dealer Name:	Dealer Code:
Repair Order #:	
Technician Name:	
Technician Signature:	