Maintenance Minder Code	Service Description Details	Estimated Avg. Service Intervals*
A	Replace engine oil and oil filter. Replace engine oil drain plug washer. Top up under hood fluids and reset tire pressures.	Every 4,000 to 9,000 miles or up to 12 months
В	Road test vehicle. Replace engine oil and oil filter. Replace engine oil drain plug washer. Inspect all fluid levels and condition of fluids. Check front and rear brake pads, rotors and brake calipers. Check parking brake adjustment. Inspect tie rod ends, steering gearbox and gearbox boots. Inspect suspension components. Inspect drive shaft boots. Inspect brake hoses and lines including VSA lines. Inspect exhaust system. Inspect fuel lines and connections.	Every 7,500 to 20,000 miles
1	Rotate tires, check and set tire pressures and hand torque all lug nuts.	Every 4,000 to 9,000 miles
2	Replace engine air filter, replace cabin pollen filter and inspect drive belt	Every 15,000 to 30,000 miles
3	Replace automatic or manual transmission fluid.	Every 30,000 to 60,000 miles
4	Replace spark plugs. Inspect condition of drive belt. Note: Valve clearance adjustment is needed at this time only when excessively noisy.	Each 7 years and 105,000 miles
5	Replace engine coolant.	Every 75,000 to 105,000 miles
Brake Fluid	Flush brake system and refill brake fluid.	Every 3 Years
Alignment	Adjust front and rear toe angles to be within factory specifications	Once every 12 months or 12,000 miles
Valve Adjustment	Adjust valve clearance and replace valve cover gasket.	Every 150,000 miles or when needed

Maintenance Minder Definitions:

Above 20%:	15 % Oil Life Remaining:	5 % Oil Life Remaining:
Service not required*	Indicates "Service Soon"	Indicates "Service Due Now"

^{*}Please note: Maintenance intervals for any Acura vehicle are based partly on Acura Maintenance Minder System prompts and should include consideration of missed services as well as vehicle maintenance, repair history, and driving conditions. If Acura Maintenance Minder does not prompt for one year after last reset, engine oil and filter should be changed, fluid levels and tire pressures checked. Environmental disposal and additional shop fees may apply and are not included in the Maintenance Minder "estimate".