

Year: 2013 to 2014	Model: <b>Acura RDX</b>	Maintenance Minder Details
--------------------	-------------------------	----------------------------

Maintenance Minder Code	Service Description Details	Estimated Avg. Service Intervals*
<b>A</b>	Replace engine oil and oil filter. Replace engine oil drain plug washer. Top up under hood fluids and reset tire pressures. Note: This model requires 0W-20 semi-synthetic motor oil.	<i>Every 4,000 to 9,000 miles or up to 12 months</i>
<b>B</b>	Road test vehicle. Replace engine oil and oil filter. Replace engine oil drain plug washer. Inspect all fluid levels and condition of fluids. Check front and rear brake pads, rotors and brake calipers. Check parking brake adjustment. Inspect tie rod ends, steering gearbox and gearbox boots. Inspect suspension components. Inspect drive shaft boots. Inspect brake hoses and lines including VSA lines. Inspect exhaust system. Inspect fuel lines and connections. Note: This model requires 0W-20 semi-synthetic motor oil.	<i>Every 7,500 to 20,000 miles</i>
<b>1</b>	Rotate tires, check and set tire pressures and hand torque all lug nuts.	<i>Every 4,000 to 9,000 miles</i>
<b>2</b>	Replace engine air filter, replace cabin pollen filter and inspect drive belt	<i>Every 15,000 to 30,000 miles</i>
<b>3</b>	Replace automatic transmission fluid and transfer fluid	<i>Every 20,000 to 40,000 miles</i>
<b>4</b>	Replace timing belt and spark plugs. Inspect condition of drive belt (add \$50.00 to replace drive belt). Inspect water pump for leakage (add \$294.95 to replace water pump and perform coolant service). Inspect timing belt auto tensioner (add \$150.00 to replace timing belt auto tensioner). Note: Valve clearance adjustment is needed at this time only when excessively noisy (add \$589.95 to adjust valve clearance and replace valve cover gaskets).	<i>Every 7 years or 105,000 miles</i>
<b>5</b>	Replace engine coolant.	<i>Every 75,000 to 105,000 miles</i>
<b>6</b>	Replace rear differential fluid.	<i>Every 15,000 to 30,000 miles</i>
<b>Brake Fluid</b>	Flush brake system and refill brake fluid.	<i>Every 3 Years</i>
<b>Alignment</b>	Adjust front and rear toe angles to be within factory specifications.	<i>Once every 12 months or 12,000 miles</i>
<b>Valve Adjustment</b>	Adjust valve clearance and replace valve cover gaskets.	<i>Every 150,000 miles or when needed</i>

### Maintenance Minder Definitions:

<b>Above 20%:</b> Service not required*	<b>15 % Oil Life Remaining:</b> Indicates "Service Soon"	<b>5 % Oil Life Remaining:</b> Indicates "Service Due Now"
--	---	---

\*Please note: Maintenance intervals for any Acura vehicle are based partly on Acura Maintenance Minder System prompts and should include consideration of missed services as well as vehicle maintenance, repair history, and driving conditions. If Acura Maintenance Minder does not prompt for one year after last reset, engine oil and filter should be changed, fluid levels and tire pressures checked. Environmental disposal and additional shop fees may apply and are not included in the Maintenance Minder "estimate".