



## Mazda 3

### 2017 Mazda SCHEDULED MAINTENANCE MENU

#### EVERY 8,000 KM OR 6 MONTHS

- Replace engine oil and filter\*<sup>1</sup>
- Inspect brake and clutch fluid, washer fluid, and coolant level
- Inspect air filter
- Inspect function of all lights
- Inspect all tires - inflation and wear\*<sup>4</sup>
- Lubricate all locks and hinges
- Rotate tires\*<sup>4</sup>

#### EVERY 24,000 KM OR 12 MONTHS

Includes 8,000 KM inspection, plus:

- Inspect and clean brake discs and pads, front and rear

#### EVERY 32,000 KM OR 24 MONTHS

Includes 8,000 KM inspection, plus:

- Inspect fuel lines and hoses\*<sup>3</sup>
- Inspect brake lines, hoses and connections
- Inspect steering operation and linkage
- Inspect front and rear suspension components, ball joints and wheel bearing axial play
- Inspect driveshaft dust boots
- Tighten bolts and nuts on chassis and body

#### EVERY 40,000 KM OR 24 MONTHS

Includes 8,000 KM inspection, plus:

- Replace cabin air filter

#### EVERY 48,000 KM OR 24 MONTHS

Includes 24,000 KM inspection, plus:

- Inspect drive belts

#### EVERY 56,000 KM

Includes 8,000 KM inspection, plus:

- Replace air filter

#### EVERY 64,000 KM OR 48 MONTHS

Includes 32,000 KM inspection, plus:

- Inspect emission hoses and tubes\*<sup>3</sup>

#### EVERY 72,000 KM OR 60 MONTHS

Includes 24,000 KM inspection, plus:

- Inspect exhaust system and heat shields

#### EVERY 120,000 KM

Includes 40,000 KM inspection, plus:

- Replace spark plugs

#### EVERY 192,000 KM OR 10 YEARS

- Replace coolant, after that every 96,000 KM or 5 years\*<sup>2</sup>

#### ADDITIONAL OPERATIONS

- Inspect flat tire repair kit annually replace tire repair fluid bottle with new one before expiration date

At each visit, we'll provide you with an exclusive Vehicle Inspection Report, which shows you the overall condition of your Mazda.

CLICK HERE FOR AN ENLARGED VERSION

TO LEARN MORE, CLICK ON LOGO



Your Mazda Dealer will provide you with a completed service checklist on every maintenance visit. In addition, your Mazda will be road tested after any servicing relating to brakes, steering or driving performance, to help verify safe functioning. Information listed in this document is accurate at time of publication and is subject to change without notice. Ask your Mazda Dealer for more detailed information. This inspection list/schedule is intended as a guide only and should not be relied upon to ensure vehicle safety. See your Mazda dealer for full details, maintenance and inspection.

Inspect is defined as: inspect and clean, repair, adjust, fill up, or replace if necessary.

\*<sup>1</sup> Reset the engine oil data after replacing the engine oil.

\*<sup>2</sup> Use of FL-22 is recommended when replacing engine coolant. Using engine coolant other than FL-22 may cause serious damage to the engine and cooling system.

\*<sup>3</sup> According to state/provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended kilometer period to ensure long-term reliability.

\*<sup>4</sup> The Tire Pressure Monitoring System (TPMS) initialization must be performed so that the system operates normally (if equipped).

CUSTOMER NAME: \_\_\_\_\_ R.O. #: \_\_\_\_\_ SERVICE ADVISOR: \_\_\_\_\_  
VIN (LAST 6 DIGITS): \_\_\_\_\_ LICENCE PLATE #: \_\_\_\_\_ ODOMETER: \_\_\_\_\_ DATE: \_\_\_\_\_

☒ **GOOD** - CHECKED OK ☒ **FAIR** - REQUIRES FUTURE ATTENTION ☒ **REPLACE** - REQUIRES IMMEDIATE ATTENTION ☐ CHECKED FOR OUTSTANDING RECALLS

## PERIMETER INSPECTION

FRONT		REAR
<input type="radio"/> Lights/lamps		<input type="radio"/> Lights/lamps
<input type="radio"/> Windshield		<input type="radio"/> Washer system
<input type="radio"/> Washer system		<input type="radio"/> Wipers/arms
<input type="radio"/> Wipers/arms		<input type="radio"/> Body damage
<input type="radio"/> Body damage		
<input type="radio"/> Horn operation		

## VISUAL INSPECTION

UNDER HOOD		UNDER VEHICLE
<input type="radio"/> Fluid levels (brakes, steering, clutch, window washer, coolant and manual/automatic transmission)		<input type="radio"/> Steering components
<input type="radio"/> Drive belt(s)		<input type="radio"/> Suspension components
<input type="radio"/> Air filter		<input type="radio"/> Shocks & Struts
<input type="radio"/> Radiator, hoses/clamps and coolant condition to: _____ °C		<input type="radio"/> Exhaust system
<input type="radio"/> Heater hoses/clamps		<input type="radio"/> CV drive axle boots (if equipped)
<input type="radio"/> Air conditioning hoses		<input type="radio"/> CHECK FOR LEAKS
<input type="radio"/> Battery/cables/clamps		<input type="radio"/> Engine oil
		<input type="radio"/> Transmission
		<input type="radio"/> Power steering
		<input type="radio"/> Coolant
		<input type="radio"/> Fuel

## BRAKE INSPECTION

☐ BRAKE INSPECTION NOT REQUIRED WITH THIS SERVICE

LF	RF	LR	RR
<input type="radio"/> Lining/pad	<input type="radio"/> Lining/pad	<input type="radio"/> Lining/pad	<input type="radio"/> Lining/pad
<input type="radio"/> Rotor	<input type="radio"/> Rotor	<input type="radio"/> Rotor	<input type="radio"/> Rotor
<input type="radio"/> Caliper	<input type="radio"/> Caliper	<input type="radio"/> Caliper	<input type="radio"/> Caliper
<input type="radio"/> Lines/hose	<input type="radio"/> Lines/hose	<input type="radio"/> Lines/hose	<input type="radio"/> Lines/hose
<input type="radio"/> Parking brake operation			

## TIRE INSPECTION

☐ FRONT \_\_\_\_\_ PSI ☐ REAR \_\_\_\_\_ PSI ☐ SPARE \_\_\_\_\_ PSI

☐ WINTER TIRES ☐ SUMMER TIRES ☐ ALL SEASON TIRES

RF	RR	LF	LR
<input type="radio"/> Tread Wear 32 <sup>nds</sup>	<input type="radio"/> Tread Wear 32 <sup>nds</sup>	<input type="radio"/> Tread Wear 32 <sup>nds</sup>	<input type="radio"/> Tread Wear 32 <sup>nds</sup>



RECOMMENDED: ☐ ROTATION ☐ ALIGNMENT  
☐ REPLACEMENT ☐ BALANCE

## YOUR NEXT MAINTENANCE APPOINTMENT

NEXT MAINTENANCE SERVICE \_\_\_\_\_ DEALER CODE \_\_\_\_\_

NEXT APPOINTMENT \_\_\_\_\_ DATE (MM/DD/YY) \_\_\_\_\_ TIME \_\_\_\_\_

## COMMENTS & RECOMMENDATIONS:

TECHNICIAN: \_\_\_\_\_

## MEASURE FRONT / REAR BRAKE LININGS

LF	RF
<input type="radio"/> 50%+	<input type="radio"/> 50%+
<input type="radio"/> 20%-50%	<input type="radio"/> 20%-50%
<input type="radio"/> 0%-20%	<input type="radio"/> 0%-20%
<input type="radio"/> 50%+	<input type="radio"/> 50%+
<input type="radio"/> 20%-50%	<input type="radio"/> 20%-50%
<input type="radio"/> 0%-20%	<input type="radio"/> 0%-20%

☐ Measurements Not Taken ☐ Declined Brake Inspection

50% or more remaining

20% - 50% remaining

Less than 20%

MAZDA GENUINE  
PARTS • SERVICE • ACCESSORIES

KEEPING THE  
EMOTION IN MOTION

WHITE - CUSTOMER COPY

PINK - SERVICE FILE COPY