

**Intermediate Maintenance Checklist – 911 GT3 (997) (2010)**

Required Maintenance and Lubrication Service (USA & Canadian Vehicles Only, Not For 911 Turbo (997), use separate checklist)

**Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual  
 After 12,000, 36,000, 60,000, 84,000 miles (20,000, 60,000, 100,000, 140,000 km) etc.

**Note:** If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

- Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.
- Change engine oil and oil filter (Every 12,000 miles/20,000 km, see separate Oil Change Sheet, PNA 000 162 GA)
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, secure installation and damage
- Coolant hoses: Check condition  
 Radiators and air intakes: Visual inspection for external debris and blockage  
 Coolant: Check level and antifreeze protection level
- Pollen filter: Replace filter element
- Brake hoses and lines: Visual inspection for damage, routing and corrosion
- Drive shafts: Visual inspection of the dust boots for leaks and damage
- Tires: Check condition and tire pressure
- Check firewall body drains for debris
- Check the door, lid locks and safety hook of the front lid for secure seating and function properly
- Vehicle lighting: Check function  
 All headlights: Check setting
- Horn: Check function
- Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)
- Check wiper blades
- Battery: Check condition and electrolyte level
- Electrical equipment, warning and indicator lights: Check function

**Additional maintenance for spark plugs** Labor operation 03 81 00 ..

- Replace spark plugs every 24,000 miles (40,000 km) or every 4 years

**Additional maintenance every 96,000 miles (160,000 km) or 12 years** Labor operation 03 86 00 ..

- Change manual transmission oil

**Every 2 years**

- Change brake fluid

**Every 4 years**

- Replace tire sealant

**After 4, then every 2 years**

- Check battery for the tire pressure monitoring system

**After 4, 8, 10, then every 2 years**

- Inspect airbag system
- Assembly and running gear mounts: Visual inspection of all rubber/hydraulic mounts for damage

Inspection Performed - Technician Signature: \_\_\_\_\_

**Road Test Check**

---

- Remote control, front seats, foot brake and parking brake (also operating travel), engine, clutch, steering, transmission, TC Switch, automatic speed control, PASM switch, Sport switch, heater, air-conditioning system and instruments:  
Check operation

---

- Oils, fluids: Visual inspection for leaks

---

Road Test Performed - Technician Signature: \_\_\_\_\_

---

**Customer Name:** \_\_\_\_\_ **Date:** \_\_\_\_/\_\_\_\_/\_\_\_\_

**VIN: WPO** \_\_\_\_\_

**Mileage** (check one)  **Miles**  **Kilometers:** \_\_\_\_\_

**Dealer Name:** \_\_\_\_\_ **Dealer Code:** \_\_\_\_\_

**Repair Order #:** \_\_\_\_\_

**Technician Name:** \_\_\_\_\_

**Technician Signature:** \_\_\_\_\_