

Minor Maintenance Checklist – 911 GT3 (997)

Required Maintenance and Lubrication Service (USA & Canadian)

Minor Maintenance (Labor Operation 03 24 00 ..) See Technical Manual
After 12,000, 36,000, 60,000, 84,000 miles (20,000, 60,000, 100,000, 140,000 km) etc.

Note: If the mileage for scheduled maintenance is not reached, minor maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

- Diagnosis system: Read fault memory; reset maintenance interval/Read and record range information on R.O.
- Change engine oil and oil filter
- Vehicle underside and engine compartment: Visual inspection for leaks (oils and fluids) and abrasion (lines and hoses); Underbody panels: visual inspection for completeness, installation and damage
- Coolant hoses: Check condition
Radiators and air intakes: Visual inspection for external debris and blockage
Coolant: Check level and antifreeze
- Pollen filter: Replace filter element
- Brake system: Visual inspection of the brake pads and brake discs for wear
- Brake hoses and lines: Visual inspection for damage, routing and corrosion
- Drive shafts: Visual inspection of the dust boots for leaks and damage
- Tires: Check condition and tire pressure
- Check firewall body drains for debris
- Check the door, lid locks and safety hook of the front lid for secure seating and function properly
- Vehicle lighting: Check function
All headlights: Check setting
- Horn: Check function
- Windshield wiper/washer system, headlight washer: Check fluid level and nozzle settings (use winter antifreeze protection during winter months)
- Battery: Check condition and electrolyte level
- Electrical equipment, warning and indicator lights: Check function

Additional maintenance for spark plugs Labor operation 03 81 00

Replace spark plugs every 24,000 miles (40,000 km) or every 4 years

Additional maintenance 48,000 miles (80,000 km) or every 6 years Labor operation 03 82 00

- Replace drive belt
- Replace fuel filter

Additional maintenance every 96,000 miles (160,000 km) or 12 years

Change manual transmission oil

Every 2 years

Change brake fluid

Every 4 years

Replace tire sealant

After 4, then every 2 years

Check battery for the tire pressure monitoring system

After 4, 8, 10, then every 2 years

- Inspect airbag system
- Mounts for engine, transmission and running gear: Visually check all rubber mounts for signs of wear and/or damage

Inspection Performed - Technician Signature: _____

Road Test Check

- Remote control, seats, foot and parking brake (also actuation travel), engine, clutch, steering, transmission, cruise control, TC switch, PASM switch, SPORT switch, heating, air conditioning system and instruments: Check function
 - Oils, fluids: Visual inspection for leaks
-

Road Test Performed - Technician Signature: _____

Customer Name: _____ **Date:** ____/____/____

VIN: WPO _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____ **Dealer Code:** _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____