



June 25, 2013

**To:** Affected North American Dealers

**Subject:** Service Bulletin S13WK Lift Area Interior Light Replacement

**Models Affected:** 2014 Model Year All American (T3FE, T3RE) Models

**Bulletin Duration:** One (1) Year from In-Service Date

**Overview**

The subject buses equipped with Feature 31051-02 Five Inch Interior Lift Light may have incorrect lights installed in the headlining above the wheelchair lift area. Service Bulletin S13WK provides instructions for installing the correct interior lights.

**Affected Units**

A printout is attached of the buses in your territory that are affected by this bulletin. Service Bulletin S13WK will be mailed to all owners on record.

**Time Allowance**

Time allowed to change the interior lights above the lift area per instructions for S13WK is 0.2hrs (12) minutes per bus.

**Repair Parts**

The parts required to perform this Bulletin must be ordered directly through Blue Bird Service Parts. Parts are available to be ordered.

**Labor Reimbursement**

Warranty applications for labor reimbursement may be submitted to Blue Bird iWarranty (Campaigns/Claims).

**Bulletin Duration**

This Service Bulletin ends one (1) year from the in-service date of the affected buses.

**Repair Facility**

Owners are being advised to contact their dealer for assistance, if needed.



BLUE BIRD

**Questions**

Questions regarding this bulletin should be directed to your Blue Bird Field Service Representative.

Sincerely,

Bill Coleman  
Engineering Services  
478-822-2242

**BLUE BIRD BODY COMPANY**

P.O. Box 937 – 402 Blue Bird Blvd – Fort Valley, Georgia – (478) 825-2021



BLUE BIRD

June 25, 2013

**To:** Select Blue Bird Customers

**Subject:** Service Bulletin S13WK Lift Area Interior Light Replacement

**Models Affected:** 2014 Model Year All American (T3FE, T3RE) Models

**Bulletin Duration:** One (1) Year from In-Service Date

**Overview**

On the subject buses equipped with Feature 31051-02 Five Inch Interior Lift Light incorrect lights may have been installed in the headlining above the wheelchair lift area. Service Bulletin S13WK provides instructions for installing the correct interior lights.

**Affected Units**

The buses in your fleet that are affected by this bulletin are identified by Blue Bird body serial number(s) on the enclosed cover sheet.

**Time Allowance**

Time allowed to change the interior lights above the lift area per instructions for S13WK is 0.2hrs (12) minutes per bus.

**Repair Parts**

The parts required to perform this Bulletin must be ordered by your dealer directly through Blue Bird Service Parts. Parts are available to be ordered.

**Labor Reimbursement**

If you perform this service bulletin yourself or have an outside repair facility perform this bulletin you may submit claims for labor and parts reimbursement to your Blue Bird dealer.

**Bulletin Duration**

This Service Bulletin ends one (1) year from the in-service date on the subject buses in your fleet.

**Repair Facility**

We encourage you to contact your Blue Bird dealer to arrange to have this Service Bulletin performed. However, you may have the option to perform this Service Bulletin yourself or have a qualified repair facility convenient to you perform this work. A qualified technician must perform work required under this bulletin.

**BLUE BIRD BODY COMPANY**

P.O. Box 937 – 402 Blue Bird Blvd – Fort Valley, Georgia – (478) 825-2021



BLUE BIRD

**Questions**

Questions regarding this bulletin should be directed to your Blue Bird Dealer.

Sincerely,

*Bill Coleman*

Bill Coleman  
Engineering Services  
478-822-2242

**BLUE BIRD BODY COMPANY**

P.O. Box 937 – 402 Blue Bird Blvd – Fort Valley, Georgia – (478) 825-2021



# Lift Area, Interior Light, Replacement

# BULLETIN

Models Affected: 2014 T3FE, T3RE, All American With 5" Interior Lift Light Feature 31051-02

## ISSUE

The interior lights installed in the wheel chair lift area on the attached list of T3 All American units are not the correct light and must be replaced.

## CORRECTIVE ACTION

Replace the two interior lights installed in the headlining above the interior wheel chair lift area.

## PROCEDURE

**WARNING:** Always follow all Federal, State, Local and Shop safety standards and use proper safety equipment, and thoroughly read and understand all instructions before performing these procedures. Observe all safety precautions to secure the bus from rolling. Park the bus on a level surface, apply parking brakes, turn off engine and remove keys. Chock wheels.

1. Using a Phillips screwdriver remove the three mounting screws from each of the existing two lights located in the interior headlining above the wheelchair lift area. Disconnect the wiring connector from the light.
2. Install new light part number 00128835 by connecting wiring connector to replacement light and attaching to same mounting holes using three screws removed in previous step.
3. Verify light operation.
4. Return bus to service.



Location View

## PARTS

Part Number	Quantity	Description
00128835	2	LIGHT, LED W/PIGTAIL CONNECTOR

S I 3 W K  
S E R V I C E B U L L E T I N